

- <---- #43 drill hole for pressed turrets, or 3/32" drill hole for swaged turrets
- $\leftarrow$   $\leftarrow$   $\leftarrow$   $\leftarrow$   $\leftarrow$   $\leftarrow$   $\leftarrow$  5/32" drill hole for board mounting
- <---- 1/4" drill hole for wire pass throughs</p>